
Xprotect as Supervisor Configuration



Once properly configured, XAtlas and XProtect automatically update in both directions, maintaining aligned common information.



In this scenario, XAtlas does not require specific configurations to interact with video surveillance system. All the configurations must be done through Milestone system


Xprotect as Supervisor Configuration





The interface configuration is performed on the XProtect Management Application, That is principally done by:


- Definition of XAtlas references
- Association of camera(s) with Access points
- Definition of Actions upon Events from the ACS



Xprotect as Supervisor Configuration of A.C. manager



Address & port that XProtect use to communicate with XAtlas




Association of cameras & gates



XProtect imports from XAtlas all access control elements (gates, doors, sensors, id points...).

One or more of the Cameras managed by XProtect can be associated to any of these access control elements



A.C. events & Video surveillance actions



