



Milestone Integration



COPYRIGHT

Please note that the content of this Document is to be considered subject to the law that regulates Copyright and is property of DAB Sistemi Integrati Srl – Rome - Italy.



Galassia 4.0 PSIM

Galassia 4.0 is a powerful PSIM+ (Physical Security Information Management) designed to supervise and integrate Complex Physical Security Systems. It's able to centralize, monitor and interconnect different kind of sensors and systems from multiple brands.

Galassia 4.0 Installation

Galassia installation consist of the following main parts:

- Galassia 4.0 Server Installation
- Microsoft SQL Server Installation
- Galassia 4.0 Client Installation
- Galassia 4.0 Videowall Driver Installation (if needed)
- Set of Drivers/Players needed to communicate to the Subsystems that should be integrated in Galassia

For all the above parts a guided installation Kit is provided.

Integration with Milestone

Integration with Milestone is activated installing the Milestone Drivers/Players Kit for Galassia (Developed by DAB Sistemi Integrati Srl)

Milestone Driver/Player Kit for Galassia will install:

- A Driver that allows the Galassia Server to communicate with Milestone Server and receive any alarm/status generated by Milestone server, as well as access to the Milestone data structure.
- A Player that allows the Galassia Client and Videowall Driver to Play Live/Playback videostreams, PTZ Cameras and extract recorded videos.

Milestone Driver/Player Kit has been developed by DAB Sistemi Integrati Srl using Milestone's SDK as a base.