Milestone configuration

Create Analytic Event



- Select Analytic Events
- Doble click to create a new Event.

Vaxtor LPR On iPRO

Milestone configuration

Milestone XProtect Management Client 2	020 R3		_	
File Edit View Action Tools Help				
🗟 🦻 😧 🗢 🛱				
Site Navigation 🗸	Analytics Events			• 9
Site Navigation Stee Navigation Speakers Microphones Metadata Speakers Metadata Support Client View Groups Matrix Rules and Events Rules Time Profiles Matrix Rules and Events Matrix Rules and Events Matrix Rules and Events Analytics Events Asis actions Security Notification Profiles Matrix Matrix Rules and Events Asis actions Security Not Speaker manager Speaker manager Speaker manager Matrix Metadata Security System Dashboard Current Tasks Server Logs Access Control Device assistant System overview Speaker manager Alarms	Analytics Events Analytics Events Analytics Events Analytics Event VaxALPR On Camera Event Vaxtor30 Vaxtor Technologies	Analytics Events Information Name: IPro Event] Description:	Test Event	
				_

• Set the Event name

File Edit View Action Tools Help		
Site Navigation + + × Analytics Events + + Analytics Events Information		→ ₽
Microphones Analytics Events Name:		
Speakers Seakers Metadata Value Substance Value Substance Value Substance Value Substance Value Substance Value Substance Value Value Substance Value Value		
- of Input - Vaxtor90 Test Even	t	
Vaxtor i echnologies		
View Groups		
Generative sand Events		
- 🖺 Rules		
- 🛞 Time Profiles		
Notification Profiles Milestone XProtect Management Client 2020 R3 X		
User-genned zvents Analytics Events		
Generic Events Op you want to save changes?		
- Visia actions		
G courity		
Pasic leve		
AXIS Optimizer Security		
C System Dashboard		
- Current Tasks		
- Every Logis		
a 🖫 Transact		
🛱 🖸 AXIS Optimizer		
B Device assistant		
- • Operator controls		
License place insis System overview		
S Speaker manager		
B-& Alarms		
	_	_

• Save new Event

Enable Analytic Events



- 1. Enable Analytic Events
- 2. Analytic Events Port

Configure Vaxtor LPR On iPRO Camera

🔢 Panasonic ALF	PR MMC - Google Chrome	_		×
A No es segu	uro 192.168.0.180/cgi-bin/adam.cgi?Language=11&methodName=sendDataToAdamApplication&installId=3A	4426E8&ls	_appData	аТу
	(TOR			
	Reporting			
	Helix			
	JSON			
	Overlay			
	XML			
	ONVIF			
	TEST			

• Enable XML reporting

Panasonic ALPR	t MMC - Google Chrome —		×
A No es segur	ro 192.168.0.180/cgi-bin/adam.cgi?Language=11&methodName=sendDataToAdamApplication&installId=3A4426E8&	s_appData	Ty
✓✓✓✓✓✓✓✓✓✓✓✓✓✓✓✓✓✓✓✓✓✓✓✓✓✓✓✓✓✓✓✓✓✓✓✓✓✓✓✓✓✓✓✓✓✓✓✓✓✓✓✓✓✓✓✓✓✓✓✓✓✓✓✓✓✓✓✓✓✓✓✓✓✓✓✓✓✓✓✓✓✓✓✓✓✓✓✓✓✓✓✓✓✓✓✓✓✓✓✓✓✓✓✓✓✓✓✓✓✓✓✓✓✓✓✓✓✓✓✓✓✓✓✓✓✓✓✓✓✓✓✓✓✓✓✓✓✓✓✓✓✓✓✓✓✓✓✓✓✓✓✓✓✓✓✓✓✓✓✓✓✓✓✓✓✓✓✓✓✓✓✓✓✓✓✓✓✓✓✓✓✓✓✓✓✓✓✓✓✓✓✓✓✓✓✓✓✓✓✓✓✓✓✓<			
≡	XML		
	Z Active		
	http://192.168.0.182:9090/		
	User		
	Password		
	Message template		
	<pre><?xml version="1.0" encoding="utf-8"?> <analyticsevent xmlns="urn:milestone-systems" xmlns:i="http://www.w3.org/2001/XMLSchema-instance"> <eventheader> </eventheader></analyticsevent></pre>		

- 1. Activate XML Reporting
- 2. <Milestone address>:<Analytic Event port> (see Enable Analytic Event)
- 3. Set XML Message template

XML Message template



- 1. Set the Camera IP (replace this IP for your camera IP)
- 2. Set created Analytic Event (see Create Analytic Event)

Milestone Analytic Event reception

Alert details

🧔 144 VaxALPR On Camera Event - AXIS P1367-E Network Camera (192.168.0.49) - Camera 1 🦳 🗸					
AXIS P1367-E Network Camera (192.168.0.49) - Camera 1 Connecting to server AXIS P1367-E Network Camera (192.168.0.49) - Camera 1 http://milestonevm:7563/	AXIS	P1367-E Network Camera Connecting to s AXIS P1367-E Netwo Camera 1 http://milestonevm:	(192.168.0.49) - Camera 1 erver ork Camera (192.168.0.49) - 7563/		
		✓ 21/02/2022	10:35:36.540 🕨 🕨		
Camera: AXIS P1367-E Network Camera (192.168.	0.49) - 🔻		Go to Alarm Time		
Instructions		Assigned to:			
ABC1234		State:	1: New 🔻		
		Priority:	1: High 🔹		
		Category:			
		ID:	144		
		Source:	AXIS P1367-E Network Camera		
		Alarm:	Plate detected		
		Message:	VaxALPR On Camera Event		
Activition		Туре:	License Plate Recognition		
Time Activity	Oumor	Rule:	Alarm Definition		
10:35 Initial state: 1: New	Owner	Location:			
10:35 Initial priority: 1: High		Tag:	ABC1234		
		Vendor:	iPro Event		
		Object:	ABC1234		
	Adr				
Help Print			ок		